


PARTS



PARTS

This list contains replaceable parts used in your heater. When ordering parts, follow the instructions listed under Replacement Parts on page 26 of this manual.


KEY NO.	PART NO.	DESCRIPTION	CFS26PT, S26PTA CFS26NT, S26NTA	QTY.
1	105441-01	Log Set	• •	1
2	104286-01	ODS Pilot	•	1
	104285-01	ODS Pilot	•	1
3	098249-01	ODS Nut	•	1
4	109053-01	Burner Outlet Tube	• •	1
5	111124-01	Burner Retainer Spring	• •	1
6	099056-29	Burner Orifice Injector	•	1
	099056-27	Burner Orifice Injector	•	1
7	101329-26	Gas Control Valve Kit	•	1
	101329-20	Gas Control Valve Kit	•	1
8	102980-01	Burner	• •	1
9	099387-09	Pilot Tube	• •	1
10	098271-10	Ignitor Cable	• •	1
11	101381-01	Piezo Ignitor and Cover	• •	1
12	098867-10	Regulator	•	1
	098867-14	Regulator	•	1
13	109052-01	Inlet Tube	• •	1
14	105990-01	Pilot Shield	•	1
PARTS AVAILABLE — NOT SHOWN				
	100563-01	Warning Plate	• •	1
	101054-01	Lighting Instructions Plate	• •	1

888-634-4289

iBuyFireplaceParts.com

888-634-4289

PARTS



PARTS

MODELS CFS26NT, CFS26PT, S26NTA AND S26PTA

This list contains replaceable parts used in your heater. When ordering parts, follow the instructions listed under Replacement Parts on page 26 of this manual.

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	108942-01CK	Top Panel, Stove	1
2	**	Pedestal Stove	1
3	108934-01CK	Stove Base	1
4	**	Stove Back Panel	1
5	108932-01CK	Louver Panel	1
6	105657-01	Blower Bracket	2
7	107363-01	Door	1
8	**	Firebox Back Panel	1
9	**	Firebox Floor	1
10	108939-01CK	Firebox Top Assembly	1
11	110419-01CK	Screen Assembly	1
12	101382-01	Valve Bracket	1
13	108978-01CK	Stove Top Trim	1
14	108944-01	Brass Trim, Firebox	2
	108944-02	Black Trim, Firebox	2
15	105576-01	Knob	1
	102874-01	Knob	1
16	101386-02	Door Hinge	2
17	099230-02	Shoulder Screw	4
18	108945-01CK	Heat Deflector	1
PARTS AVAILABLE — NOT SHOWN			
	101054-01	Lighting Instructions Plate	1
	100563-01	Warning Plate	1
	104108-06	Metallic Black Touch-Up Paint Kit	1

** Not a field replaceable part.