


PARTS

MODELS SVYD18PRA AND SVYD18NRA



PARTS

This list contains replaceable parts used in your heater. When ordering parts, follow the instructions listed under Replacement Parts on page 26 of this manual.

KEY NO.	PART NO.	DESCRIPTION	QTY.
1	104026-01	Stove Log	1
2	103778-01	ODS Pilot	1
	103779-01	ODS Pilot	1
3	098249-01	ODS Nut	2
4	104423-02	Burner Outlet Tube	1
	104423-01	Burner Outlet Tube	1
5	098264-02	Male Connector	1
6	111124-01	Burner Retainer Spring	1
7	099056-19	Burner Orifice Injector	1
	099056-26	Burner Orifice Injector	1
8	102980-01	Burner	1
9	099387-13	Pilot Tube	1
	099387-15	Pilot Tube	1
10	103781-02	Gas Control Valve	1
	103781-01	Gas Control Valve	1
11	103345-02	Lower Bracket	1
12	M11084-38	Screw, #8 x 0.38	7
13	**	Painted Base Assembly	1
14	098271-10	Ignitor Cable	1
15	102445-01	Piezo Ignitor	1
16	103587-02	Plate, Switch	1
17	098304-01	Screw	2
18	103784-04	Flame Adjustment Knob Extension	1
19	103784-03	Off-Pilot-On Knob Extension	1
20	M12461-26	Screw, Hex Slit Wsr 10-32 x 0.38	4
21	100609-01	Pilot Tube (Regulator to Pilot)	1
22	099918-02	Pilot Regulator	1
23	103284-02	Wiring Harness	1
24	099998-01	Switch	1
PARTS AVAILABLE — NOT SHOWN			
	100563-01	Warning Plate	1
	103877-01	Lighting Instructions Plate	1
	100565-01	Warning Plate Fastener	1
	101137-04	Hardware Kit	1

**Not a field replaceable part.

SYD18PRA
 SYD18NRA

888-634-4289

888-634-4289

888-634-4289

PARTS


OXFORD™
VCIS(*) SERIES AND PVCIS(*) SERIES

VICTOR HEARTH®
VH(*)A SERIES

(* Indicates Color Suffix Designation)

iBuyFireplaceParts.com

888-634-4289



PARTS

OXFORD™ VCIS(*) SERIES AND PVCIS(*) SERIES AND VICTOR HEARTH®

VH(*)A SERIES (* Indicates Color Suffix Designation)

This list contains replaceable parts used in your heater. When ordering parts, follow the instructions listed under Replacement Parts on page 26 of this manual.

KEY

NO.	PART NO.	DESCRIPTION	QTY
1L	104171-11	Top Grate with Screen - Left (Black Only)	1
1C	104171-08	Top Grate with Screen - Center (Black Only)	1
1R	104171-12	Top Grate with Screen - Right (Black Only)	1
2	111532-01CK	Stove Back Panel (Black Only)	1
3	104173-01	Bottom Door (Charcoal)	1
	104173-07	Bottom Door (Porcelain Enamel Red)	1
	104173-08	Bottom Door (Porcelain Enamel Green)	1
	104173-09	Bottom Door (Porcelain Enamel Sand)	1
	104173-23	Bottom Door (Porcelain Enamel Black)	1
4	111531-02CK	Stove Dropped Bottom	1
5	104175-01	One Leg (Charcoal) (4 Total Per Stove)	1
	104175-07	One Leg (Porcelain Enamel Red) (4 Total Per Stove)	1
	104175-08	One Leg (Porcelain Enamel Green) (4 Total Per Stove)	1
	104175-09	One Leg (Porcelain Enamel Sand) (4 Total Per Stove)	1
	104175-44	One Leg (Porcelain Enamel Black) (4 Total Per Stove)	1
6	104176-01	Leg Leveler bolt M8 x 1.25 - 55 mm Long (4 Total Per Stove)	1
7	104177-01	Hardware Kit	1
7-1	**	Door Hinge Step Bolt With Shoulder (1 Per Unit)	1
7-2	**	Door Catch Bolt M8 x 1.25 - 55 mm Long With Two M8 Hex Nuts (1 Per Unit)	1
7-3	**	Bottom Floor Bolts M6 x 1 - 25 mm Long With Flat Washer And Lock Washer (4 Per Unit)	1
7-4	**	Leg Bolts M8 x 1.25 - 20 mm Long With Flat Washer And Lock Washer (4 Per Unit)	1
8	104178-01	Back Panel Bolts M6 x 1 - 20 mm Long With Flat Washer And Lock Washer (4 Per Unit)	1
9	113086-01	Left Door, Black (Oxford™ Only)	1
	113086-02	Left Door, Porcelain Black (Oxford™ Only)	1
	113086-03	Left Door, Porcelain Green (Oxford™ Only)	1
	113086-04	Left Door, Porcelain Red (Oxford™ Only)	1
	113086-05	Left Door, Porcelain Sand (Oxford™ Only)	1
	111972-01	Left Door, Black (Victor Hearth® Only)	1
	111972-02	Left Door, Porcelain Enamel Black (Victor Hearth™ Only)	1
	111972-03	Left Door, Porcelain Enamel Green (Victor Hearth™ Only)	1
10	113087-01	Right Door, Black (Oxford™ Only)	1
	113087-02	Right Door, Porcelain Black (Oxford™ Only)	1
	113087-03	Right Door, Porcelain Green (Oxford™ Only)	1
	113087-04	Right Door, Porcelain Red (Oxford™ Only)	1
	113087-05	Right Door, Porcelain Sand (Oxford™ Only)	1
	111972-04	Right Door, Black (Victor Hearth® Only)	1
	111972-05	Right Door, Porcelain Enamel Black (Victor Hearth® Only)	1
	111972-06	Right Door, Porcelain Enamel Green (Victor Hearth® Only)	1
PARTS AVAILABLE — NOT SHOWN			
	104108-01	Touch-up Spray Paint 12 oz Can (Charcoal)	1
	104807-01	Touch-up Paint Bottle with Brush (Porcelain Enamel Red)	1
	104807-02	Touch-up Paint Bottle with Brush (Porcelain Enamel Green)	1
	104807-03	Touch-up Paint Bottle with Brush (Porcelain Enamel Sand)	1
	104807-04	Touch-up Paint Bottle with Brush (Porcelain Enamel Black)	1